

TECHNICAL INFORMATION

KLEEN
PURGATIS

DISHWASHING DETERGENT powder and tabs • without dosage technology

TRYMAT ULTRA



Art. No. 90.203.949 5 x 60 x 18-g-box

- with glass protection, chlorine-free
- alkaline and highly effective dishwashing detergent concentrate
- removes stubborn stains and impurities such as tea and coffee
- good water scale compatibility
- less foaming
- low wastewater pollution and environmentally friendly
- prevents the build-up of starch
- for use in industrial single tank and household dishwashers

APPLICATION RANGE:

The dishwashing detergent tabs are only to be used in industrial single tank and household dishwashers. Trymat Ultra tabs are always to be used together with an acidic rinse aid (e.g. Prestan Klar Forte).

INSTRUCTIONS FOR USE AND DOSAGE:

Use 1 tab per washing cycle in normal cases. Place the tab in the dosing chamber or simply place it in the machine. Permit the dishwashing program to run correctly! **Note:** It is recommended that there is always a sufficient amount of special salt in the salt storage container when using machines with an installed decalcification system (ion exchanger)! It is otherwise to be ensured that there is a sufficient quantity of rinse aid in the corresponding storage tank **If improperly used, there will be no legal claims accepted for any resulting damage.**

TECHNICAL DATA:

Form: square two-layer tab
1st layer: white, 2nd layer: green
pH-value in a 1% solution: 11

INGREDIENTS:

Under 5 %: non-ionic surfactants, polycarboxylate, phosphonate
5-15 %: bleaching agent on an oxygen basis
Über 30 %: phosphate
Contains: enzymes (protease, amylase), fragrances
Stability: min. 1 year in the original container, protect from frost and heat

The surfactants contained in this preparation comply with the biodegradability criteria as laid down in Regulation (EC) No. 648/2004 on detergents.

LABELLING:



Warning

Hazard statements: H319: Causes serious eye irritation.
EUH208: Contains protease. May produce an allergic reaction.

Precautionary statements: P102: Keep out of reach of children.
P305+351+338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P337+313: If eye irritation persists: Get medical advice/attention.
P301+312: IF SWALLOWED: Call a POISON CENTRE/doctor if you feel unwell.

TRANSPORT: Not hazardous goods in the sense of these transport regulations. Do not subject to a temperature exceeding 40°C.

KLEEN PURGATIS GmbH

Headquarters

Dieselstraße 10
D-32120 Hiddenhausen
Fon +49 (0) 5223 9970-40
Fax +49 (0) 5223 9970-195
info@kleen-purgatis.de

An Affiliated Company of the BUDICH GROUP

Kleen Purgatis International AG

Firststrasse 30A
CH-8835 Feusisberg
Fon +41 (0) 44 515 35 60
Fax +41 (0) 44 515 35 69
info@kleen-purgatis.ch

www.kleen-purgatis.com